

Acronyms: BDE = IDOT's Bureau of Design & Environment CREATE = Chicago Region Environmental & Transportation Efficiency CTCO = Chicago Transportation Coordination Office DBE = Disadvantaged Business Enterprise DPIT = IDOT's Division of Public & Intermodal Transportation EA = Environmental Assessment ECAD = Environmental Class of Action Determination EIS = Environmental Impact Statement FHWA = Federal Highway Administration FP&PS = Feasibility Plan & Project Screening IC = Implementation Committee IDOT = Illinois Department of Transportation NTA = Notice to Advertise NTP = Notice to Proceed PS&E = Plans, Specifications & Engineer's Estimate RFP = Request for Proposal RR = Railroad SRA = State Rail Agreement


WEB = Internet

## Revised: 01/17/2012 – Approved by CREATE Partners 07/30/2015 – Revised by CREATE Partners

Sources CREATE Phase II and Phase III Flow Process CREATE Final Feasibility Plan Amendment 1 CREATE Phase I Reports and Design Approval Procedures IDOT BDE Procedures Manual and Updates

This CREATE flow chart does not include IDOT or CDOT sponsored grade separations or emergency project approvals. These are handled through separate agency or CREATE processes.

## CREATE Phase I Work Flow Process



Note 5 – If NEPA class of action changed to EA or EIS, consult with FHWA to determine what, if any, coordination is needed with cooperating and participating agencies. This may include coordinating items such as purpose and need, as well as alternatives.

Note 6 – See CREATE Program Public Involvement Guidelines for Rail Projects for more details.

Report) required for design approval.

Note 7 – See CREATE Program Rail Projects Phase I Reports and Design Approval Procedures for policies and guidelines regarding report development, format and type (i.e., Abbreviated Project Report or Project

JINS SRA → IDOT issues N	TP Phase I (Part B) is now	RR begins Phase I Engineering (Part B)	If Phase I SRA RR begins billing
		(Part B)	
IDOT signs Class of Action Determination Document	FHWA signs Class of Action Determination Document		
No			
er is d?			
			IDOT Action
	Official End of Phase I Activities		RR Action
	Note: See CREATE Phase II and Phase III flow process chart for concurrent Phase I and Phase II activities		FHWA Action
			BDE Action
		Imple	mentation Committee (IC) Action
		Map	CTCO Action agement Committee
			Action REATE Stakeholder
			Committee
		Phase	e I (Part A) Consultant e I (Part B) Consultant
			Lead RR Agency)